

**Lieferant / Supplier:**

BSH Hausgeräte GmbH,
Carl-Wery-Str. 34,
D-81739 München,
Tel. +49 89 20 355 777

Hersteller / Manufacturer:

Bavariapool Thomas Emmerichs GmbH
Gewerbering 11, D-82140 Olching, Germany



e 500 ml

en Degreaser for home appliances for intensive cleaning of tough grease on kitchen cupboards and units, tiles, extractor hoods, microwaves, hobs and stainless steel surfaces. **Contains:** < 5% amphoteric surfactants, < 5% non-ionic surfactants.

Generic Name	Degreaser for home appliances
Net Quantity	1 N
Net Volume	500 ml
Maximum Retail Price	Rs 1199.00 (inclusive of all taxes)
Unit Sale Price	Rs 2.398 / ml
Best Before	5 Years from manufacturing date
Manufacturing date (dd/mm/yyyy)	See on bottle
Imported and Marketed by (Registered Office)	BSH Household Appliances Manufacturing Pvt. Ltd., Arena House, 2nd Floor Main Building, Plot No. 103, Road no. 12, MIDC, Andheri (E), Mumbai 400093, Maharashtra India
Customer Care – For any complaints, grievances or feedback, please contact	Bosch Consumer Care, Toll Free No. 1800 266 1880 Email ID: service.in@bosch-home.com Siemens Consumer Care, Toll Free No. 1800 209 1850 Email ID: service.in@siemens-home.com Gaggenau Consumer Care, Toll Free No. 1800 266 1683 Email ID: service.in@gaggenau.com or you can write to us at the above mentioned address
Country of origin	Germany



© A.I.S.E.



**Bottle body made of
100 % recycled material.**

IN Article No. 00312293



de en ! INFO!





de Fettleöser für Haushaltsgeräte für die intensive Oberflächenreinigung von hartnäckigem Fettschmutz auf Küchenmöbel, Fliesen, Dunstabzugshaube, Mikrowelle, Herd und Edelstahloberflächen.

Gebrauchsanweisung: Gleichmäßig aufsprühen, 3–5 min. wirken lassen, mit Schwamm / weichem Tuch abwischen, mit Wasser nachreinigen, gegebenenfalls wiederholen und dann trockenpolieren. Heiße Oberflächen bis max. 30–40 °C reinigen. Gelösten Schmutz und Reiniger unbedingt vollständig mit Wasser abwaschen. Bei Edelstahl flächendeckend aufsprühen oder mit weichem Tuch gleichmäßig aufbringen, dann wie obenstehend weiter vorgehen.

Empfehlung: Original Tuch eCloth (Artikel-Nr. 00312327) verwenden.

Enthält: < 5 % amphotere Tenside, < 5 % nichtionische Tenside.

Rezeptur ohne Mikroplastik.

en Degreaser for home appliances for intensive cleaning of tough grease on kitchen cupboards and units, tiles, extractor hoods, microwaves, hobs and stainless steel surfaces.

Instructions for use: Spray evenly and leave for 3–5 minutes. Wipe with sponge or soft cloth, rinse with water, repeat if necessary, then polish and dry. Clean warm surfaces up to a maximum of 30–40 °C. Thoroughly rinse and wipe away the grease and cleaning fluid. For stainless steel, spray evenly over the whole surface or apply with soft cloth, then proceed as above.

Recommendation: Use an eCloth (article number 00312327) in conjunction with this product.

Formula without micro plastic.



de Nachbestellmöglichkeiten

en Re-order information

Online shop

IN Article No. 00312293

www.bosch-home.com/store

www.siemens-home.bsh-group.com/store

www.gaggenau.com/store

Importeur: IN 1800 266 1880, BSH Household Appliances Mfg. Pvt. Ltd., Arena House, 2nd Floor Main Building, Plot No. 103 Road No. 12, MIDC, Andheri East, Mumbai 400093, India

00312293-Ne02/13032025

