






KENWOOD

English

KAH740PL

instructions



Kenwood Ltd









New Lane
Havant
Hampshire
PO9 2NH

kenwoodworld.com

© Kenwood Ltd 2018



138058/1



English

safety

- Read these instructions carefully and retain for future reference.
- Remove all packaging and any labels.
- Switch off and unplug the kitchen machine:
 - before fitting and removing parts;
 - after use;
 - before cleaning.
- Never use a damaged attachment. Get it checked or repaired : see 'service and customer care'.
- Never use an unauthorised attachment.
- Never leave the appliance on unattended.
- Always wait until the blades have completely stopped before removing the bottle from the High Speed Outlet.
- **⚠ The bottle is only suitable for use with cold ingredients. Do not process hot ingredients.**
- **SCALD RISK:** The unit may also be used for making soups. Liquids should be allowed to cool to room temperature before placing in the bottle or blending.
- Never drink any hot liquids from the bottle.
- When drinking through the lid, take care that the drink is smooth. Some experimentation may be necessary to achieve the desired result, particularly

when processing firm or unripened foods as you may find that some ingredients remain unprocessed.

- Do not touch the sharp blades. Keep the blade unit away from children.
- Always take care when handling the blade assembly and avoid touching the cutting edge of the blades when cleaning.
- Do not blend frozen ingredients or ice cubes without liquid.
- Never blend dry ingredients (e.g. spices, nuts) or run the Blender empty.
- Do not use the Blender as a storage container.
- Some liquids increase in volume and froth during blending e.g. milk, so do not overfill and ensure the blade assembly is correctly fitted.
- To ensure long life of your Blender, never run it continuously for longer than 60 seconds.
- Never blend food that has formed a solid mass during freezing, break it up before adding to the bottle.
- Never blend more than the maximum capacity (600ml) marked on the bottle.
- Only use the Blender with the blade assembly supplied.
- Never fit the blade unit to the High Speed Outlet without the Blender bottle fitted.

- When removing the Blender from the power unit:
 - wait until the blades have completely stopped;
 - do not accidentally unscrew the Blender bottle from the blade unit.
- Misuse of your Blender can result in injury.

Refer to your main Kitchen Machine instruction book for additional safety warnings.

- This appliance conforms to EC Regulation 1935/2004 on materials and articles intended to come into contact with food.

You can use your Blender for making delicious and nutritious cold drinks. The dispensing lid means that it can easily be converted into a sports bottle.

A selection of recipes can be found at the back of the instructions. Combinations of fruit and yoghurt (both fresh and frozen), ice cream, ice cubes, juice and milk can be used.

before using for the first time

- Wash the parts: see 'care & cleaning'.

key

- ① dispensing lid × 2
- ② sports bottle × 2
- ③ sealing ring
- ④ blade unit
- ⑤ blade holder

to assemble your blender attachment **(A→C)**

- 1 Add ingredients to the bottle up to the 600ml level mark.
 - For best blending performance always add ice/frozen ingredients to the bottle first.
 - When adding frozen ingredients (i.e. frozen fruit, yoghurt, ice cream or ice) do not blend more than 60g or 3 ice cubes.
 - Do not blend frozen ingredients without liquid.
- 2 Fit the sealing ring ③ to the blade unit ④, ensuring the seal is located correctly in the grooved area.
 - Leaking will occur if the seal is damaged or incorrectly fitted.
- 3 Hold the underside of the blade unit ④ and lower it onto the bottle, blades down.
- 4 Screw the blade holder ⑤ onto the bottle - turn clockwise to lock.
 - Shake to disperse the ingredients.

to use your blender attachment **(D→E)**

- 1 Remove the high speed outlet cover.
- 2 Place the blender over the high speed outlet with the line up graphic ▼ on the blade holder facing forward. Turn clockwise and at the same time push down until the unit engages. Then turn further clockwise until the attachment locks into position.

Speed	Max operating time
Max	60 secs

- Allow the ingredients to blend until smooth.

after blending **(F)**

- 1 When the desired consistency is reached, turn the speed control to the 'O' off position.
- 2 Hold the blade holder and turn anti-clockwise to release the blender. Then remove the blender supporting it with both hands.
- 3 Turn the bottle the other way up and unscrew the blade assembly.

using the drinking lid **(G)**

- 1 Fit and lock the lid by turning clockwise.
- 2 When you want to drink, simply flip open the lid cover. The drink can be consumed straight from the bottle.

hints & tips

- Note that when the bottle is filled to max capacity (600ml), this is approximately two servings.
- If you do not intend to consume your drink immediately, keep it refrigerated.
- Ensure your drink is thin enough to be able to drink from the dispensing lid. To make a thinner drink add more liquid.
- Once your drink has reached the desired consistency, you can use the pulse 'P' to ensure all ingredients are thoroughly blended. Use the pulse 'P' to operate in a start stop action to control the texture of your drink.
- After blending, some drinks may not be completely smooth due to seeds or the fibrous nature of ingredients.
- Some drinks may separate on standing, therefore it is best to drink them straight away. Separated drinks should be stirred before drinking.
- When the dispensing lid is fitted always keep the bottle upright.

care & cleaning

- Always switch off, unplug and dismantle before cleaning.
- Always wash immediately after use.
- Do not let food dry onto the blade assembly as this will make cleaning difficult.

blade assembly (I)

- Unscrew the blade assembly from the bottle. Then lift out the blade unit.
- **Care should be taken when removing the blade unit from the blade assembly.**

- 1 Remove and wash the sealing ring.
- 2 Do not touch the sharp blades - brush them clean using hot soapy water, then rinse thoroughly under the tap.






Do not immerse the blade assembly in water.

- 3 Leave to dry upside down away from children.

other parts

Wash by hand, rinse with clean water and dry.

(H) The following table shows which items can be washed in the dishwasher.

Item	Suitable for dishwashing
	✓
	x
	x
	✓
	✓

service and customer care

UK only

If you need help with:

- using your attachment
- servicing or repairs (in or out of guarantee)

☎ call Kenwood customer care on **023 9239 2333**.

● spares and attachments

☎ call 0844 557 3653.

other countries

- If you experience any problems with the operation of your attachment, before requesting assistance refer to the “troubleshooting guide” section in the manual or visit www.kenwoodworld.com.
- Please note that your product is covered by a warranty, which complies with all legal provisions concerning any existing warranty and consumer rights in the country where the product was purchased.
- If your Kenwood product malfunctions or you find any defects, please send it or bring it to an authorised KENWOOD Service Centre. To find up to date details of your nearest authorised KENWOOD Service centre visit www.kenwoodworld.com or the website specific to your Country.
- Designed and engineered by Kenwood in the UK.
- Made in China.

troubleshooting guide

Problem	Cause	Solution
The Blender will not operate.	No power.	Check kitchen machine plugged in.
Can not fit blender to high speed outlet.	The ▼ graphic to assist alignment is not facing forward.	Place the blender over the high speed outlet with the line up graphic ▼ on the blade holder facing forward. Turn clockwise and at the same time push down to engage.
Poor blending performance.	Insufficient liquid added.	Add more liquid and follow recipes supplied.
	Bottle overfilled.	Do not fill above 600ml level mark.
	Insufficient processing time.	Process for 60 seconds.
Poor processing of frozen ingredients.	Ice/frozen ingredients added to bottle last.	For best blending performance always add ice/ frozen ingredients to bottle first.
	Too much frozen ingredients added.	Do not process more than 60g frozen ingredients or more than 3 ice cubes.
Pouring action from lid spout poor.	Drink consistency too thick.	Process for longer or add more liquid.
Blender leaking from blade assembly.	Seal missing. Seal incorrectly fitted. Seal damaged.	Check seal is fitted correctly and not damaged. To obtain a replacement seal see "service and customer care".
	Bottle not tightened sufficiently to blade holder.	Check bottle fitted correctly to blade holder.
If none of the above solve the problem see "Service and Customer Care".		



**IMPORTANT INFORMATION
FOR CORRECT DISPOSAL
OF THE PRODUCT IN
ACCORDANCE WITH THE
EUROPEAN DIRECTIVE ON
WASTE ELECTRICAL AND
ELECTRONIC EQUIPMENT
(WEEE)**

At the end of its working life, the product must not be disposed of as urban waste.

It must be taken to a special local authority differentiated waste collection centre or to a dealer providing this service.

Disposing of a household appliance separately avoids possible negative consequences for the environment and health deriving from inappropriate disposal and enables the constituent materials to be recovered to obtain significant savings in energy and resources.

As a reminder of the need to dispose of household appliances separately, the product is marked with a crossed-out wheeled dustbin.

recipes

Breakfast Smoothies

breakfast 2GO

1 serving (300ml)

- 2 ice cubes (40g)
- 60ml skimmed milk
- 50g low fat yoghurt
- 50g banana cut into 2cm slices
- 75g apple, chopped into 2cm chunks
- 5ml wheatgerm
- 5ml runny clear honey

- 1 Add ingredients to bottle in order stated. Shake well before blending.
- 2 Switch to MAX for 60 seconds. Check the sweetness and add the Honey if required.

nutty banana boost

1 serving (250ml)

- 75ml semi-skimmed milk
- 115g low fat hazelnut yoghurt
- 50g banana cut into 2cm slices
- 3 ready to eat dried apricot, chopped into 1cm pieces

- 1 Add ingredients to bottle in order stated. Shake well before blending.
- 2 Switch to MAX for 45 seconds.

Fruity Smoothies

iced strawberry sensation

1 serving (250ml)

- 2 ice cubes (40g)
- 70ml apple juice
- 60g strawberries, hulled and halved
- 80g cantaloupe melon, seeded and cut into 2cm chunks
- 5ml runny clear honey

- 1 Add ingredients to bottle in order stated.
- 2 Pulse 5 times, then switch to MAX for 45 seconds. Check the sweetness and add the Honey if required.

summer fruit smoothie

1 serving (250ml)

- 50g frozen summer fruit mix
- 200ml semi-skimmed milk

- 1 Add ingredients to bottle in order stated.
- 2 Switch to MAX for 30 seconds.

mix smoothie

1 serving (250ml)

- 120g carrot
- 70g apple
- 75g orange (peeled)
- 50ml yoghurt
- 50ml semi skimmed milk

- 1 Cut the apple, orange and carrot into 2 cm chunks.
- 2 Add ingredients to bottle in order stated.
- 3 Pulse 5 times, then switch to Max for 45 seconds.

Vegetable Smoothies

green smoothie

1 serving

- 180g orange juice
- 15g kale
- 2tbsp (30ml) parsley
- 1tbsp (15ml) coriander
- 10 -12 mint leaves
- 110g banana cut into 2cm slices

- 1 Add ingredients to bottle in order stated.
- 2 Switch to MAX for 30 seconds.

emerald smoothie

1 serving

- 3 ice cubes (60g)
- 135g orange juice
- 45g yoghurt
- 25g spinach leaves
- 115g pineapple cut into 2cm pieces

- 1 Add ingredients to bottle in order stated.
- 2 Switch to MAX for 45 seconds.

Protein Shake

blueberry supergreens shake

1 serving

- 60g frozen blueberries
- 275ml skimmed milk
- 10g protein powder
- 60g banana cut into 2cm slices
- 40g spinach

- 1 Add ingredients to bottle in order stated.
- 2 Switch to MAX for 30 seconds.